ENGLISH

HUBLOT

You have chosen a Hublot watch; you are about to enter a whole new world…

Every piece cultivates its distinction, to assert its powerful and incredible personality every time. Yet this formidable wealth of materials, functions, colours and shapes, gives rise to a singular watchmaker: Hublot.

Committed to the concept of “the Art of Fusion” and fuelled by this spirit of innovation, the Swiss watchmaking manufacture Hublot represents the link between watchmaking tradition and modernity, creating fusions of unexpected high-performance elements such as carbon, zirconium, tantalum, titanium, tungsten, ceramic and aluminium with more conventional materials such as gold, steel, diamonds and precious stones – while developing traditional movements, always with an innovative and creative design.

This fundamental concept makes your watch a unique timepiece. As you turn this page, you will enter the world of the Big Bang, Classic Fusion and King Power… – where each watch attests to the fusion between tradition and innovation.

# MANUAL INSTRUCTION
## WARRANTY

The card at the end of your Hublot kit is an electronic warranty certificate, which contains your watch's identity code, and also grants you privileged access to the Hublotista area available on the Hublot website (www.hublot.com). The card must be activated electronically, or completed and the Hublot stamp applied.

Each Hublot watch bears an individual identification number, which proves its authenticity. Your Hublot watch is guaranteed against all manufacturing defects for a period of two years from the date of purchase, provided that the watch was purchased from an approved Hublot retailer. However, this warranty does not cover damage caused by inappropriate use or handling of the watch.

For any repair during the warranty period, please enclose with the watch the pre-activated warranty card signed by an approved Hublot retailer, an exhaustive list of which can be found on our website.

Should the watch require any kind of servicing, please contact an approved Hublot retailer or After-Sales service centre only, the contact details of which can be found on the Hublot website.

All repairs or servicing work carried out by third parties not authorised by Hublot will automatically invalidate your warranty; in which case any damage would be rectified at your expense.

# RECOMMENDATIONS & CARE

The constituent parts of your Hublot watch are all of the finest quality, and inspected under extremely stringent criteria. They combine to form a piece with exceptional water resistance, which may reach 4000 metres. To preserve these qualities, we recommend a complete overhaul every 3 to 5 years, since temperature variations, humidity, perspiration and repeated shocks may affect its water resistance as the years go by.

With its water resistant case and rubber, ceramic or carbon strap, or gold or steel bracelet, your Hublot watch can be washed easily. If the watch has an alligator strap, you are advised to take it off when bathing. Clean it regularly in lukewarm soapy water, rinsing and wiping down carefully with a soft cloth. After wearing your Hublot watch in seawater, please rinse it in fresh water.

# QUICK START

## CROWN FUNCTIONS

Crown positions:

0. screw-in crown
1. winding
2. date setting
3. time setting



# SCREW-IN CROWN

position 0

## CONCERNS REFERENCES 312/322/731/732

This type of crown offers excellent protection to ensure the case's water resistance.

The crown has to be unscrewed before any operation and must be screwed back in fully afterwards.

This type of crown can be found only on diving watches guaranteed water resistant beyond 300 m in depth.

## USE

1. Unscrew the crown before any operation.
2. Press the crown firmly against the case while screwing it back in.

Occasionally, check that the crown is screwed in correctly.

**The Big Bang model does not have a screw-in crown because this watch is equipped with the latest technology of a double protective gasket, ensuring water resistance to 100 m.**

1.



2.



# WINDING

position 1

## CONCERNS ALL MECHANICAL AND SELF-WINDING WATCHES

This function accumulates the energy required by your watch to run properly.

## USE

**Self-winding**

This term means that your watch automatically stores the energy generated by your arm movements when the watch is worn on your wrist.



If your watch has not been worn for some time and has stopped, you must wind it manually by rotating the crown clockwise through approximately ten turns. See drawing.

**For models with screw-in crowns, do not forget to screw the crown back in completely to ensure its water resistance.**

# DATE SETTING 7

position 2

CONCERNS ALL MODELS EQUIPPED WITH A DATE

This function enables you to set the date displayed by the watch rapidly, without changing the time, using only the crown.

**It is strongly recommended not to make this correction between 8 pm and 1 am, as the calendar disc is "engaged" during this period, so the operation might damage the mechanism.**

## USE

1. Pull the crown out to position 2.
2. Turn the crown clockwise (or anti-clockwise, according to the model) until the desired date appears in the window.
3. Press the crown back in completely against the case.

**For models with screw-in crowns, do not forget to screw the crown back in completely to ensure its water resistance.**



# TIME SETTING

position 3

CONCERNS ALL MODELS

This function enables you to set the time of your watch using the crown.

**When performing this operation, make sure that the calendar date change is at midnight and not at midday.**

## USE




1. Pull the crown out to position 3 (or position 2 if the watch does not have a date function), at the exact moment when the seconds hand is at the 12 o'clock position; the hand will then stop.
2. Then turn the crown either way to set the hour and minute hands to the desired time.
3. Press the crown back in completely against the case; the watch will restart.

**For models with screw-in crowns, do not forget to screw the crown back in completely to ensure its water resistance.**

# BATTERY

## CONCERNS ALL QUARTZ MODELS

Quartz watches are powered by a battery. The battery needs to be changed if the watch exhibits time loss, stops completely, or if the seconds hand jumps in 4-second steps. Take advantage of battery replacements to have the gaskets and crown checked, and if necessary have them replaced, by an approved Hublot retailer.

# ROTATING BEZEL OR FLANGE

## CONCERNS REFERENCES 312/322/731/732

Only diving models are equipped with this function. It lets the wearer know the remaining dive time at any moment, or can be used to measure the various decompression stages to be followed before rising to the surface.

To ensure maximum safety, the bezel has been designed to rotate in one direction only.



## USE

When used by a diver, the rotating bezel must be set to zero (fluorescent pointer on the graduation) so that the time taken by the minute hand to reach this point shows the desired dive time. When the minute hand reaches zero on the rotating bezel, the diver must have surfaced.

Lift up the guard to release the crown, then unscrew it and set the dive time. Screw the crown back in properly and re-close the guard.

# CHRONOGRAPH

## CONCERNS REFERENCES
## 301/311/317/318/341/342/521/701/703/716/719/748

The chronograph function enables you to measure a time.

The dial features 2 or 3 counters:

**For 301/311/703 models**
The hour counter is at the bottom, and the minute counter on the right; the left-hand counter shows the elapsing time, and the seconds are counted by the central direct-drive hand.

**For 341/342/521/541 models**
The hour counter is at the bottom, and the minute counter on the left; the right-hand counter shows the elapsing time, and the seconds are counted by the central direct-drive hand.

**For 317/318 models**
The 45-minute counter is on the left, while the right-hand counter shows the elapsing time; the seconds are counted by the central direct-drive hand, and there is no hour counter. The Chukker Bang model is equipped with a 7.5-minute counter.

**For 716/732/748 models**
The minute counter occupies the entire dial (central hand). The left-hand counter shows the elapsing time. The central minute counter is 45-min, 48-min or 60-min, according to the model.

**For models 701 UNICO Manufacture**

The 60-minute counter is on the right, the seconds counter is in the centre, while the small seconds counter on the left shows the elapsing time.

**For 719 models**

The minute counter is on the right, the seconds counter is in the centre, as is the second split-seconds hand. The elapsing time small seconds is on the left, while the power reserve is at the bottom.

## OPERATION

1.


Before timing, make sure that the chronograph centre hand (direct-drive), and the minute and hour counter hands have been reset. Then:

1. Press push-piece (A):
   the chronograph hand will start instantly.
2. When the event ends, press push-piece (A):
   the hand will stop and display the exact elapsed time.
3. Press push-piece (B):
   the direct-drive hand and counter hands will be reset.

2.


To measure a series of sequential times: press push-piece (A) again to restart the hands.

3.


**N.B.: the chronograph can only be reset if it has first been stopped by pressing push-piece (A).**

## FLYBACK FUNCTION

If your watch is equipped with the flyback function (e.g. UNICO movement), you can switch between timing measurements with a single press, instead of three.

1. Activate the chronograph by pressing push-piece (A).
2. To go directly to the next sequence, press push-piece (B), which will restart your chronograph with a new time measurement.

## SPLIT-SECONDS FUNCTION

If your watch is equipped with the split-seconds function (e.g. 315/715 or 719 models), which means that you can use the chronograph to determine a split time while continuing to measure a time:

1. Hold down the crown push-piece (C) – or “split” push-piece for the 719 model – once the chronograph is running: a split-seconds hand under the direct-drive hand will stop, to indicate a split time.
2. Press the crown push-piece (C) again – or the “split” push-piece for the 719 model – the split-seconds hand will instantly catch up to the direct-drive hand so that they are superimposed.

# POWER RESERVE

In principle Hublot watches have a power reserve of 42 hours, except for a few models such as the UNICO, a manufacture movement which has a 72-hour power reserve.